Alarm Code	Incorrect Indoor Unit No. Setting

- Alarm code is displayed on the master controller/ the 7-segment of O.U. display PCB / the 7-segment of I.U. PCB1.

★ This alarm code is displayed when the duration of automatic addressing of indoor unit exceeds 5 minutes after power-on of outdoor unit.
★ This alarm code is displayed when the number of connected indoor units exceeds the maximum allowed.
★ This alarm code is displayed when refrigerant system No. set by DSW6 on O.U. display PCB in the same H-NET.

NOTE:

- In the case of H-NET system, this alarm code may be displayed when DSW4 (for refrigerant system No. setting) on the O.U. display PCB7 and DSW8 (for refrigerant system No. setting) on the indoor unit PCB1 are not set correctly. In this case, turn OFF the power supply and set them correctly, and turn ON the power supply again.