Alarm Code 13	Activation of Inverter Overcurrent Protection Device (2)

- Alarm code is displayed on the master controller/ the 7-segment of O.U. display PCB / the 7-segment of I.U. PCB1.

★ If instantaneous overcurrent (Cause code of inverter stoppage = 2) or electronic thermal protection(Cause code of inverter stoppage = 4) occurs on inverter , the compressor stops. The operation automatically restarts after three minutes. If this occurs again five times in the next * minutes, this alarm code is displayed.

Model	*
050-100	60

