Alarm code	65	Transmission failure between Indoor unit and Master Controller

- Alarm code is displayed on the master controller/ the 7-segment of O.U. display PCB / the 7-segment of I.U. PCB1.
- Alarm code is displayed when there is no communication between indoor unit PCB1 and the Master Controller for 5 minutes.
- Reset the unit to release the alarm.

