Alarm Code 6A	Inverter Failure

- Alarm code is displayed on the master controller/ the 7-segment of O.U. display PCB / the 7-segment of I.U. PCB1.

★ This alarm code is indicated when the following phenomenon occurs three times in 30 minutes.
(Retry operation is performed for the first two times.)

Condition of Activation only for 050-100 units:
① Inverter PCB receives communication error (Cause code of inverter stoppage=17)
② Inverter has not operated for 3 seconds, although O.U. PCB requests operation.

