Alarm Code 60	Abnormality of Current Sensor

- Alarm code is displayed on the master controller/ the 7-segment of O.U. display PCB / the 7-segment of I.U. PCB1.

★ If abnormal fault of sampling circuit (Cause code of inverter stoppage = 8) occurs on inverter , the compressor stops. The operation automatically restarts after three minutes. If this occurs again 2 times in the next 30 minutes, this alarm code is displayed.

