Alarm code	F2	Alarm sent by Outdoor unit (Outdoor unit alarm except sensor alarm and 5D).

- Alarm code is displayed on the master controller / the 7-segment of I.U. PCB1.
- Reset the unit to release the alarm.