Alarm code	H2	Wired Remote Controller and Master Controller transmission alarm.

- This alarm is displayed only on Master Controller.
- Wired Remote Controller is configured as room thermostat but no Wired Remote Controller is detected.
- Reset the unit to release the alarm.