Alarm code	71	Protection Thermostat of DHW Electric Heater activation

- Alarm code is displayed on the master controller/ the 7-segment of O.U. display PCB / the 7-segment of I.U. PCB1.
- This alarm is displayed when the temperature inside the DHW tank exceeds the safety temperature and protection thermostat is activated (field supplied).
- Reset the unit to release the alarm.

