Alarm code	72	Protection Thermostat of Auxiliary Electric Heater Activation

- Alarm code is displayed on the master controller/ the 7-segment of O.U. display PCB / the 7-segment of I.U. PCB1.
- This alarm is displayed when the temperature inside the auxiliary electric heater exceeds the safety temperature and protection thermostat is activated.
- Reset the unit to release the alarm.

