Alarm code	F1	Alarm sent by Outdoor unit (Outdoor unit alarm 21-29).

- Alarm code is displayed on the master controller / the 7-segment of I.U. PCB1.
- Reset the unit to release the alarm.

Alarm code	F2	Alarm sent by Outdoor unit (Outdoor unit alarm except 21-29 and EE).

- Alarm code is displayed on the master controller / the 7-segment of I.U. PCB1.
- Reset the unit to release the alarm.

Alarm code	F3	Alarm sent by Outdoor unit (Outdoor unit alarm EE).

- Alarm code is displayed on the master controller / the 7-segment of I.U. PCB1.
- Reset the unit to release the alarm.

Alarm code	H2	Wired Remote Controller and Master Controller transmission alarm.

- This alarm is displayed only on Master Controller.
- Wired Remote Controller is configured as room thermostat but no Wired Remote Controller is detected.
- Reset the unit to release the alarm.