
Alarm code	51	Hydraulic flow rate abnormality alarm (WP1)

- Alarm code is displayed on the master controller/ the 7-segment of O.U. display PCB / the 7-segment of I.U. PCB1.
- This alarm is displayed when there is a low flow rate abnormality in the hydraulic system as following and the same condition occurs three times or more within 60 minutes.
  Note:The detection is invalid when DSW5-1 ON.
- Reset the unit to release the alarm.



NOTE

Check Water Pump1 feedback in "Alarm Code 8D".