Alarm code	8D	Water Pump (WP1) malfunction

- Alarm code is displayed on the master controller/ the 7-segment of O.U. display PCB / the 7-segment of I.U. PCB1.
- This alarm is displayed when faulty iPWM output of WP1 is detected and the same condition occurs three times or more within 60 minutes. Referring to EC WP1 Water flow feedback.
  Note: The detection is invalid when DSW5-1 ON.
- Reset the unit to release the alarm.

