Alarm code	76	Freeze Protection Stop by indoor unit temperature thermistors

- Alarm code is displayed on the master controller/ the 7-segment of O.U. display PCB / the 7-segment of I.U. PCB1.
- This alarm code is displayed when the following conditions are detected and the same condition occurs three times or more within 3 hours
  - Condition 1: Meet any of following conditions during defrosting operation:
    (1) TL+ TowHP ≤ 4[°C] and TL ≤ 1[°C] lasting for 260s.
    (2) TL ≤ 1[°C] lasting for 100s.
  - Condition 2: Meet any of following conditions during cooling operation:
    (1) TL+ TowHP ≤ 4[°C] and TL ≤ 1[°C] lasting for 180s.
    (2) [TL ≤ -4°C and Tg ≤ 8°C] or [Tg ≤ 1°C] lasting for 240s.
    (3) [TL ≤ -16°C and Tg≤ 8°C] or [Tg ≤ -1°C] lasting for 60s.
- Reset the unit to release the alarm.

